



- 1- Select a tent ground site free of sharp sticks, roots, rocks or any other object that might damage your tent. Lay the inner tent wide open in the ground with the door in a prevailing wind direction (door away from the wind). Make sure the door is fully zipped (closed).
- 2- Sort and assemble the 5 tent fiberglass poles making sure that the pole end fully inserts into the metal ferrule end to avoid splitting or breaking the poles.
- 3- Insert the two red poles through the pole sleeves which are marked with the red binding and attach the pin at the diagonal tent corners. These poles are the main central poles and cross over each other to support the main central body of the tent.
- 4- Insert the 2 white poles through the pole sleeves which are marked with the white binding and attach the pin at the diagonal tent corners. After doing this your inner tent will be erected.
- 5- Clip all c clips from the inner tent to the poles. This will complete the inner tent set up. Now you are ready to peg down the inner to the ground inserting the pegs in a 45 degrees angle away from the tent.
- 6- Pull the fly over the frame and peg out the corners points of the fly. Never over-tighten or pull excessively on fly as it can stretch a seam and may cause leaks. Insert the shorter white pole through the pole sleeve which is inside the fly front and then put the two tips of the pole into the eyelet on the front of the tent. There are plastic clips to attach the fly to the metal rings at the pegging points. Attach the p/tie attachments on the inside of the fly to the poles and guy out the attached guy ropes to complete the set up of your tent. These guy ropes assist in keeping the tent stable during windy conditions and should always be pegged out when the tent is erected.
- 7- The dismantle process of the tent is the reverse of the preceding instructions and special care should be taken in removing the pegs (never pull on the material to remove the pegs, use a peg remover or other peg) and make sure that the pegs and tent materials are dry and clean before packing away. A wet tent will mildew quickly and will void your warranty.

DISASSEMBLE OF YOUR TENT

This process of the tent is the reverse of the preceding instructions and special care should be taken in removing the pegs (NEVER PULL ON THE TENT TO REMOVE STAKES AS THIS COULD RESULT IN PROPERTY DAMAGE OR PERSONAL INJURY, use a peg remover or other peg) and make sure that the pegs and tent materials are dry and clean before packing away. A wet tent will mildew quickly and will void your warranty.

Easy color coded setup system



WARNINGS

- Under certain conditions (cold weather, high humidity, etc.) condensation will form on the inside of your tent. Condensation is caused by water vapor from your breath, perspiration, or any wet clothing inside the tent. It is NOT LEAKAGE through the tent fabric. It can be minimized by removing wet clothing from your tent and providing good ventilation through the tent.
- Tree limbs, tree sap, bird droppings, or moisture steadily dripping of tree limbs can cause damage to the tent fabric and its coating resulting in leaks or loss of flame-resistant properties.
- Never store tent, even for a short period of time, without drying it thoroughly and brushing off caked dirt. Do not pack stakes or poles inside your tent. Use separated storage bag.
- Stakes should be removed by pulling on the stake itself. NEVER PULL ON THE TENT TO REMOVE STAKES AS THIS COULD RESULT IN PROPERTY DAMAGE OR PERSONAL INJURY.
- Tent poles should not be left telescoped together during storage.
- Do not leave your tent set-up for weeks at a time. Be aware that exposure to ultraviolet rays from the sun can seriously damage material and/or cause it to become discolored.

Our tents are made with such care and dedication using the latest available technology and most experienced labor. How much it will last does not depend only on our care but mainly on how YOU care about your tent. READ carefully the instructions and warnings and set up the tent at home before going outdoors to make sure all parts are in place and that you are familiar with it. The warranty is limited to 6 months after the date of purchase and covers material and workmanship defects only.

This tent must be properly ventilated in all weather conditions. Even in extreme weather. Note that snow can obstruct air-flow and cause asphyxiation unless cleared frequently.

Never use fuel burning, oxygen consuming devices (i.e. heaters, lanterns, stoves, bongs or other flame sources) inside your tent, this will cause asphyxiation and possible fire hazard

ATENCIÓN

- En ciertas condiciones climáticas, aparecerá condensación en la parte interior de su carpas. Esto es causado por la transpiración de nuestros cuerpos o de ropas húmedas que estén dentro de la carpas.
- No deje su carpas armadas por más de 15 días seguidos.
- Puede haber pequeñas filtraciones de agua por las costuras, principalmente por los puntos donde más se estira. Para evitar que eso suceda aplique dos capas de impermeabilizante náutica u otro sobre el área afectada o en toda la costura con frecuencia.
- Use siempre los vientos (cuerdas) para dar mayor estabilidad o impermeabilidad y separar el cubretecho del dormitorio, pero nunca tensione demasiado.
- Para sacar las estacas de la tierra no use las huinchas de la carpas, podría rasgarla.
- Antes de guardar su carpas, asegúrese de que esté totalmente seca y que las estacas estén limpias y embalado cada ítem en su respectiva bolsa.
- Nunca arme su carpas cerca del fuego.
- Busque siempre un lugar con sombra, seguro y plano para armar su campamento.
- Nunca deje comida abierta dentro o fuera de la carpas en la zona de camping, eso podría atraer animales y/o insectos indeseados.

La garantía de nuestros productos es de 6 meses, siendo tres meses de garantía legal y tres meses de garantía contractual mediante la presentación de la boleta de compra y constatación de defecto de fabricación. La determinación de defecto de fabricación es realizada por un técnico de nuestra empresa. Si se constata un defecto de fabricación el producto será cambiado por uno nuevo. Si el defecto es causado por la manipulación el producto será reparado, testeado y certificado que está apto para el uso y se devolverá el mismo.

ATENÇÃO

- Em certas condições climáticas, aparecerá condensação na parte interna de sua barraca. Isto é causado pela transpiração de nossos corpos ou de roupas úmidas que estão dentro da barraca.
- Não deixe sua barraca armada por mais de 15 dias seguidos.
- Podem haver pequenas infiltrações d'água pelas costuras, principalmente nos pontos onde mais se estica. Para evitar que isso ocorra, aplique duas camadas de impermeabilizante Nautika ou outro sobre a área afetada ou em toda costura com frequência.
- Use sempre as cordinhas para dar maior estabilidade e impermeabilização ao separar o sobre-teto do dormitório, mas nunca tensione demais.
- Para puxar as estacas da terra, não use as alças da barraca, você poderá rasgá-las.
- Antes de embalar sua barraca, esteja seguro de que está totalmente seca e que as estacas estejam limpas e embale cada ítem em sua respectiva bolsa. Nunca dobre tudo junto.
- Nunca arme sua barraca perto do fogo.
- Procure sempre um lugar sombreado, plano e seguro para montar seu acampamento.
- Nunca deixe comida aberta dentro ou fora da barraca na zona de camping, isso pode atrair animais e/ou insetos indesejados.

A garantia de nossos produtos é de 6 meses sendo 3 meses de garantia legal mais 3 meses de garantia contratual, mediante a apresentação de nota ou cupom fiscal, se constatado defeito de fabricação. A determinação de defeito de fabricação é realizado por um técnico em nossa empresa. Se constatado defeito de fabricação o produto será substituído por um produto novo. Se o defeito for ocasionado pelo manuseio, o produto será consertado, testado e certificado que está apto ao uso e será devolvido.

RESPECT AND PROTECT NATURE
PROTEGA LA NATURALEZA
PROTEJA A NATUREZA



40 years building a lifestyle
40 anos construindo um estilo de vida

WWW.NAUTIKALAZER.COM.BR

Todos os direitos reservados. Importa & Distribui para o Brasil:

NAUTIKA Com de Artigos de Lazer Ltda

CNPJ 08.712.193/0001-15

Tel 11-2085-4622 - sac@nautika.com.br

WWW.NTKGLOBAL.COM

All rights reserved

Todos los derechos reservados

International Recreational Products LLC Global

Customer Service 305-592-9472 - cs@ntkglobal.com